

Le Creuset Cookware Knob Sizing Guide



Signature Gold Knob

Safe at any oven temperature, our Signature Gold Knob instantly dresses up Le Creuset cookware with elegant shine and is shaped for a better grip.

Size	Stock No.	Fits
Small	LS9435-37	Round Dutch Oven: 1 qt.
		Oval Dutch Oven: 1 qt.
		Signature Braiser: 1 ½ qt.
		Signature Saucepan: 1 ¾ qt.
Medium	LS9435-47	Round Dutch Oven: 2 qt., 3 ½ qt.
		Oval Dutch Oven: 2 ¾ qt., 3 ½ qt.
		Signature Saucepan: 2 ¼ qt., 3 ¼ qt.
Large	LS9435-57	Round Dutch Oven: 4 ½ qt., 5 ½ qt., 7 ¼ qt., 9 qt., 13 ¼ qt.
		Oval Dutch Oven: 5 qt., 6 ¾ qt., 8 qt., 9 ½ qt., 15 ½ qt.
		Signature Braiser: 3 ½ qt., 5 qt.



Signature Phenolic Knob

The enhanced composite knob on the Signature Range is larger for a better grip, with increased heat resistance up to 500° F.

Size	Stock No.	Fits
Small	LS9431-47	Round Dutch Oven: 1 qt., 2 qt., 3 ½ qt.
		Oval Dutch Oven: 1 qt., 2 ¾ qt., 3 ½ qt.
		Signature Braiser: 1 ½ qt.
		Signature Saucepan: 1 ¾ qt., 2 ¼ qt., 3 ¼ qt.
Large	LS9431-57	Round Dutch Oven: 4 ½ qt., 5 ½ qt., 7 ¼ qt., 9 qt., 13 ¼ qt.
		Oval Dutch Oven: 5 qt., 6 ¾ qt., 8 qt., 9 ½ qt., 15 ½ qt.
		Signature Braiser: 3 ½ qt., 5 qt.



Classic Phenolic Knob

The Classic Phenolic Knob is oven-safe up to 390° F and replaces worn or broken knobs, freshening a variety of older cast iron cookware.

Size	Stock No.	Fits
Small	L9431N-45	Round Dutch Oven: 1 qt., 2 qt., 3 ½ qt.
		Oval Dutch Oven: 1 qt., 3 ½ qt.
		Saucier Pan: 2 ¼ qt.
		Chef's Oven: 1 ½ qt., 3 ½ qt.
Large	L9431N-55	Round Dutch Oven: 4 ½ qt., 5 ½ qt., 7 ¼ qt., 9 qt., 13 ¼ qt.
		Oval Dutch Oven: 5 qt., 6 ¾ qt., 9 ½ qt., 15 ½ qt.



Signature Stainless Steel Knob

The Signature Stainless Steel Knob is safe at any oven temperature and features an updated design for an easy grip.

Size	Stock No.	Fits
Small	LS9434-37	Round Dutch Oven: 1 qt.
		Oval Dutch Oven: 1 qt.
		Signature Braiser: 1 ½ qt.
		Signature Saucepan: 1 ¾ qt.
Medium	LS9434-47	Round Dutch Oven: 2 qt., 3 ½ qt.
		Oval Dutch Oven: 2 ¾ qt., 3 ½ qt.
		Signature Saucepan: 2 ¼ qt., 3 ¼ qt.
Large	LS9434-57	Round Dutch Oven: 4 ½ qt., 5 ½ qt., 7 ¼ qt., 9 qt., 13 ¼ qt.
		Oval Dutch Oven: 5 qt., 6 ¾ qt., 8 qt., 9 ½ qt., 15 ½ qt.
		Signature Braiser: 3 ½ qt., 5 qt.
Signature Wok: 5 qt.		



Classic Stainless Steel Knob

The Classic Stainless Steel Knob adds shine to Le Creuset cookware as a replacement and is safe at any oven temperature.

Size	Stock No.	Fits
Small	L9404-40	Round Dutch Oven: 1 qt.
		Oval Dutch Oven: 1 qt.
		Chef's Oven: 1 ½ qt.
Medium	L9404-50	Round Dutch Oven: 2 qt., 3 ½ qt., 4 ½ qt., 5 ½ qt.
		Oval Dutch Oven: 3 ½ qt., 5 qt., 6 ¾ qt.
		Saucier Pan: 2 ¼ qt.
Chef's Oven: 3 ½ qt.		
Large	L9404-55	Round Dutch Oven: 7 ¼ qt., 9 qt., 13 ¼ qt.
		Oval Dutch Oven: 9 ½ qt., 15 ½ qt.

