



How to program your Saki Bread Machine

Thanks for purchasing the Sake bread machine from Joseph's Kitchen! We are excited to get you started to bake your first loaf of bread! Please note that certain bread recipes may recommend different settings. You can find the video on how to set up your bread machine in the link below.

<https://youtu.be/iZlctlDMijA>

Step 1

Plug in the machine. This is an attached cord on the back of the machine.

Step 2

Once Plugged in, turn on the machine. You will find this button at the top right corner. (Circled in green)



Step 3

Press the Program button (circled in green) until you reach menu number 12 as shown. This is the Home-Made Program



Again, please note that some recipes may call for different recommended settings. Be sure to try out your recipe as it may need altered for your best results. If you experience any issues, please contact us at support@josephskitchen.com.

Step 4

Set the **FIRST KNEAD** setting by pressing the Selection button. (circled in green)



Set the timer for the **FIRST KNEAD** setting by changing the arrows pointing up and down to **20** mins.



Step 5

Set the **FIRST REST** setting by pressing the Selection button once. (circled in green)



Set the timer for the **FIRST REST** setting by changing the arrows pointing up and down to **30 minutes**.



Step 6

Set the **SECOND KNEAD** setting by pressing the Selection button once. (circled in green)



Set the timer for the **SECOND KNEAD** setting by changing the arrows pointing up and down to **0** mins.



Step 7

Set the **SECOND REST** setting by pressing the Selection button once. (circled in green)



Set the timer for the **SECOND REST** setting by changing the arrows pointing up and down to **15** mins.



Step 8

Set the **THIRD KNEAD** setting by pressing the Selection button once. (circled in green)



Set the timer for the **THIRD KNEAD** setting by changing the arrows pointing up and down to **10** mins.



Step 9

Set the **THIRD REST** setting by pressing the Selection button once. (circled in green)



Set the timer for the **THIRD REST** setting by changing the arrows pointing up and down to **20** mins.



Step 10

Set the **FOURTH KNEAD** setting by pressing the Selection button once. (circled in green)



Set the timer for the **FOURTH KNEAD** setting by changing the arrows pointing up and down to **0** mins.



Step 11

Set the **FIRST RISE** settings by pressing the Selection button once. (circled in green)



Set the timer for the **FIRST RISE** setting by changing the arrows pointing up and down to **0** mins.



Step 12

Set the **SECOND RISE** settings by pressing the Selection button once. (circled in green)



Set the timer for the **SECOND RISE** setting by changing the arrows pointing up and down to **0** mins.



Step 13

Set the **THIRD RISE** settings by pressing the Selection button once. (circled in green)



Set the timer for the **THIRD RISE** setting by changing the arrows pointing up and down to **0** mins.



Step 14

Set the **BAKE** settings by pressing the Selection button once. (circled in green)



Set the timer for the **BAKE** setting by changing the arrows pointing up and down to **45** mins.



You are now ready to bake bread!